

DROP IN SHELF AND DRAWER UNIT

MOD DR24-D

INSTALLATION SHEET


NO TOOLS REQ.

For a proper installation please follow step by step the sheet provided in the drawer.



AVAILABLE IN:

- DRY OAK
- CHERRY
- ESPRESSO



HARDWARE PACK

DESCRIPTION		QTY
SHELF SUPPORT PINS (Place shelf support pins where you desire your drop in shelf and Drawer Unit to be set).		4
8 mm DOWELS (See figure No.2).		2
BACK HOLDOWN SUPPORT (See Figure No.1).		2

DEAR CUSTOMER:

To ensure that you have a speedy and pleasant time assembling your unit PLEASE READ THE INSTRUCTIONS CAREFULLY BEFORE BEGINNING ASSEMBLY.

If you need assistance, **DO NOT CALL THE STORE**, call us.

Our Customer Service Group is here to help you.

**CALL BETWEEN 8:00am to 3:00pm
PACIFIC TIME.**

Please be sure to follow the construction order in the Assembly Manual and complete each step before you proceed.

Call:

USA:


Plycraft Industries Inc.
2100 E. Slauson Ave.
Huntington Park, CA 90255
Email: plycraft@ix.netcom.com

**Toll Free Telephone # 1-800 -7659035
Tel # 1-323-587-8101
Fax # 1-323-587-8220.**

FOR PROPER INSTALLATION:

Follow **STEP BY STEP** the sheet provided in the drawer.

Figure No.1



NOTE:


Please refer to Figure No.1 so you can locate where the back holdown support pin must be placed.

DRAWER FRONT ALIGNMENT:

If your DRAWER FRONT does not close properly, there is an adjustment inside the drawer box on the back portion of your DRAWER FRONT.

Loosen the middle knob at the center of the front and adjust left or right to line up the drawer front.

(REFER TO PAGE 3)



FOR PROPER INSTALLATION:

Follow **STEP BY STEP** the sheet provided in the drawer.


Figure No.2


NOTE:

Please refer to Figure No.2 so you can locate where the dowel pins must be placed.

IMPORTANT:


Dear Customer, please make sure the two dowels are inserted completely into the holes to prevent the DRAWER FRONT from coming out.





DRAWER FRONT ALIGNMENT:

Loosen middle knob screw and move to adjust left or right to line up your drawer front correctly.



DRAWER FRONT ADJUSTMENT:

Loosen the knob as shown in the figure.